

BICYCLE REPAIR WORKSTAND

INSTRUCTIONS MANUAL

1. Open the leg quick release, then pull down the extension leg and close the quick release securely.
2. Open the quick release, then extend to desired height and close the quick release securely.
3. Open the quick release, then pull the lock lever and push up the arm into position, and close the quick release securely.
4. Clamp on bike seat post or frame properly, close the handle lever and rotate the Clamp to set the width (don't over-tighten).
5. Adjust to desired angle by rotating the angle handle lever and lock it properly.

WARNING: IT CAN CAUSE DAMAGE OR INJURY TO PROPERTY OR PERSONS WHEN FAIL TO TIGHTEN OR CLOSE THE QUICK RELEASE OR HANDLE LEVER. WHEN YOU ADJUST THE HEIGHT OF THE STAND, PLEASE HOLD THE TOP PART. No lubricant or maintenance needed for the bike work stand.

